



## Interchangeability of parts Series 136

Structure product number  
136.XYZ.WW.UV

|    |                                                                    |
|----|--------------------------------------------------------------------|
| X  | type (1-6)                                                         |
| Y  | Version (count nr. 1-9; 1= smallest; 9= biggest type)              |
| Z  | <b>Stem size</b> (1-6; 1= biggest; 6= smallest bore)               |
| WW | Material code                                                      |
| U  | Thread type (A = G1/4, B = 1/4 NPT)                                |
| V  | Housing version (2= standard (round); 6= square (like series 156)) |

The housing and stem are inseparably connected to each other. All other parts are interchangeable, but cannot be combined in every way. The possible combinations are shown in the table. **Nozzles of the same stem size** can be interchanged by **exchanging the mouthpiece**. The number of the mouthpiece is shown in small letters below the number of the nozzle.

|               |   | Stem size                     |                                                                    |                                                                    |                                                                    |                                                                    |                                                                    |
|---------------|---|-------------------------------|--------------------------------------------------------------------|--------------------------------------------------------------------|--------------------------------------------------------------------|--------------------------------------------------------------------|--------------------------------------------------------------------|
| Building type |   | 1                             | 2                                                                  | 3                                                                  | 4                                                                  | 5                                                                  | 6                                                                  |
|               | 1 |                               | 136.142<br>136.142.WW.00.03.0                                      |                                                                    | 136.134<br>136.134.WW.00.03.0                                      | 136.115<br>136.115.WW.00.03.0<br><br>136.125<br>136.125.WW.00.03.0 |                                                                    |
|               | 2 | 136.231<br>136.231.WW.00.03.0 | 136.222<br>136.222.WW.00.03.0                                      |                                                                    |                                                                    | 136.215<br>136.215.WW.00.03.0                                      |                                                                    |
|               | 3 | 136.351<br>136.351.WW.00.03.0 | 136.342<br>136.342.WW.00.03.0                                      |                                                                    | 136.324<br>136.316.WW.00.03.0<br><br>136.334<br>136.334.16.00.03.0 |                                                                    | 136.316<br>136.316.WW.00.03.0                                      |
|               | 4 |                               | 136.462<br>136.462.WW.00.03.0<br><br>136.452<br>136.452.WW.00.03.0 | 136.443<br>136.443.WW.00.03.0<br><br>136.433<br>136.433.WW.00.03.0 | 136.414<br>136.414.WW.00.03.0                                      | 136.425<br>136.425.WW.00.03.0                                      |                                                                    |
|               | 5 |                               |                                                                    |                                                                    |                                                                    | 136.525<br>136.525.WW.00.03.0                                      | 136.516<br>136.525.WW.00.03.0                                      |
|               | 6 | 136.691<br>136.691.WW.00.03.0 | 136.682<br>136.616.WW.00.03.0                                      | 136.673<br>136.673.WW.00.03.0                                      | 136.654<br>136.616.WW.00.03.0<br><br>136.664<br>136.626.WW.00.03.0 | 136.635<br>136.616.WW.00.03.0<br><br>136.645<br>136.626.WW.00.03.0 | 136.616<br>136.616.WW.00.03.0<br><br>136.626<br>136.626.WW.00.03.0 |

Example: The 136.231 can be converted to a 136.351 or a 136.691 by using a different mouthpiece

Attention! When replacing the mouthpiece, the characteristics (mixing, spray angle, flow rate) of the nozzle will change. The data can be found in the catalog.