


## Rotating cleaning nozzle MaxiSpinner 2 Series 5M4





## **Features:**

- Hygienic design
- Suitable for high temperatures
- · Made entirely of stainless steel











Max. temperature 250 °C



Installation Operating in every direction possible



**Bearing**Double ball bearing made of stainless steel 316L



Material Stainless steel 316L



Recommended operating pressure 2 bar



Filtration Line strainer with a mesh size of 0,1mm/170 mesh

**FDA** 



Adapter 1 1/4 BSPP and 1 1/2 BSPP are compatible with HygienicFit





Spray angle	Ordering no.					Narrowest	V water [l/min]				Max. tank
	Туре	Connection				free cross section	• water [//mm]				diameter [m]
				1 1/2" Slip-on	2"- Slip-on	Ø [mm]	p [bar] (p <sub>max</sub> = 7 bar)*				1
		1 1/4 1 1/2 BSPP BSPP					1,0	2,0	3.0	at 40 psi [US gal/min]	
180°	5M4.253.1Y	AQ	AS	TF15	TF20	1.8	95	135	165	42	4.0
180°	5M4.254.1Y	AQ	AS	TF15	TF20	2.1	95	135	165	42	4.0
270°	5M4.365.1Y	AQ	AS	TF15	TF20	2.5	177	250	306	78	5.0
360°	5M4.279.1Y	AQ	AS	TF15	TF20	1.7	107	150	184	46	4.0
	5M4.329.1Y	AQ	AS	TF15	TF20	2.0	141	200	245	62	4.5
	5M4.369.1Y	AQ	AS	TF15	TF20	2.3	177	250	306	78	5.0

NPT thread and weld-on versions on request.

The max. tank diameter shown above applies for the recommended operating pressure and has to be seen as a recommendation. The cleaning result is also affected by the type of soiling

Operating with compressed air only for short-term usage. Operation above the recommended operating pressure has negative effects on the cleaning result and wear.

## Information slip-on connection

- Bolt with head incl. pin made of stainless steal 316L included (Ordering no. 05M.431.1Y.00.00.0).
- Depending on diameter of the adapter, the flow rate increase due to leakage between connecting pipe and rotating cleaning nozzle.
- Minimum insertion diameter (with mounted bolt) is the same as for the threaded variants 69 mm.

MaxiSpinner 2

 $<sup>^{\</sup>star}$  Please note the maximum operating pressure of 4 bar for the 2" slip-on connection.